Sharp **DV-NC70** DVD/VHS combo

DVD menu

Press the **GREEN ON** button to turn on the multimedia projector
The projector takes about a minute to warm up

To change the **'source'** press the **GREEN** button to select
Computer, **Video** or **DVD**

Turn the projector off by pressing the **RED OFF** button
The message **Please wait a moment** will display on the screen
It takes about 90 seconds for the projector to shut down

NB
The remote control is required to control most DVD/VHS functions and is available for loan from Multimedia Resources in the library

Volume control *

AV POWER turns on the loud speakers and power for the DVD/VHS player

On the remote control and the player, **ORANGE**=**VHS** and **GREEN**=**DVD**

On the REMOTE, slide this button to **VCR** or **DVD**

On the PLAYER, press here to select **VHS (ORANGE)** or **DVD (GREEN)**

*** in some rooms this control knob is not present. In these rooms use volume controls indicated here**

Please remember to turn all equipment off when you are finished